


Optima Click



Mounting System



- 1 Place the front part of the hinge on the front side of the mounting plate.




- 2 Rotate the arm of the hinge.




- 3 Press down the rear part of the hinge to Click on.


Adjusting System






Depth adjustment
Acting on the "A" screw it is possible to adjust the distance between the side of the cabinet and the door.




Independent side adjustment
Acting on the "B" screw it is possible to change the amount of the door covering on the side of the cabinet.




Vertical adjustment
Acting on the "C" screw of the mounting plate it is possible to adjust the door vertically.




CRANK 0
For lay-on doors



CRANK 8
For partial lay-on doors



CRANK 15
For inset doors



		Drilling distance (K)						
		3	4	5	6	7		
Overlay (C)	19					2		
	18				2			
	17			2		4		
	16		2		4			
	15	2		4		6		
	14		4		6			
	13	4		6				
	12		6					
	11	6						
		Mounting plates (H)						

		Drilling distance (K)						
		3	4	5	6	7		
Overlay (C)	11					2		
	10				2			
	9			2		4		
	8		2		4			
	7	2		4		6		
	6		4		6			
	5	4		6				
	4		6					
	3	6						
		Mounting plates (H)						

		Drilling distance (K)						
		3	4	5	6	7		
Overlay (C)	0	2		4		6		
	1		4		6			
	2	4		6				
	3		6					
	4	6						
		Mounting plates (H)						

Table to determinate the minimum distance **A** so that a door with **T** thickness can open without protrusion from the cabinet and without interfering with adjacent doors.

T=	16	17	18	19	20	21	22	23	24	25	26
K=3 A=	0.55	0.75	1.10	1.45	1.80	2.40	3.10	3.90	4.70	6.70	6.50
K=4 A=	0.55	0.70	1.05	1.40	1.75	2.25	2.85	3.60	4.35	5.75	6.00
K=5 A=	0.53	0.70	1.00	1.35	1.65	2.10	2.65	3.30	4.00	4.75	5.55
K=6 A=	0.50	0.70	0.95	1.25	1.60	2.00	2.50	3.05	3.70	4.40	5.20
K=7 A=	0.50	0.65	0.85	1.20	1.55	1.90	2.35	2.85	3.45	4.10	4.80